

digital

InfoServer Client for OpenVMS

LASTCP and LADCP Utilities

Order Number: AA-PT4DA-TE

InfoServer Client for OpenVMS

LASTCP and LADCP Utilities

Order Number: AA-PT4DA-TE

This manual describes the LASTCP and LADCP utilities. You use the LASTCP utility to configure the LASTport transport protocol on your OpenVMS system, and you use the LADCP utility to manage InfoServer device services.

Revision/Update Information:	This is a new manual.
Software Version:	InfoServer Software Version 2.0 or later
Operating System Version:	VMS Version 5.0 or later

**Digital Equipment Corporation
Maynard, Massachusetts**

October 1992

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1992.

All Rights Reserved.

The postpaid Reader's Comments forms at the end of this document request your critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation: DEC, DECUS, DECnet, DIGITAL, LASTport, LAT, PATHWORKS, VAX, VAXcluster, OpenVMS, and the DIGITAL logo.

PostScript is a registered trademark of Adobe Systems Incorporated.

This document was prepared using VAX DOCUMENT, Version 2.0.

Contents

Preface	v
LASTCP Utility	
LASTCP Description	LASTCP-1
Invoking and Exiting the Utility	LASTCP-1
LASTCP Help Facility	LASTCP-2
Starting InfoServer Client for OpenVMS Software Automatically	LASTCP-2
Startup Restrictions: PATHWORKS and RSM	LASTCP-2
Startup Restrictions: SYSMAN	LASTCP-3
User Account Requirements	LASTCP-3
SYSGEN Parameter MAXBUF Requirement	LASTCP-3
LASTCP Commands	LASTCP-4
EXIT	LASTCP-5
HELP	LASTCP-6
SHOW CIRCUIT COUNTERS	LASTCP-7
SHOW CLIENTS	LASTCP-8
SHOW LINE COUNTERS	LASTCP-9
SHOW NODE CHARACTERISTICS	LASTCP-11
SHOW NODE COUNTERS	LASTCP-13
SHOW SERVERS	LASTCP-14
SHOW STATUS	LASTCP-16
SHOW TRANSPORT COUNTERS	LASTCP-17
START TRANSPORT	LASTCP-19
STOP TRANSPORT	LASTCP-22
ZERO COUNTERS	LASTCP-23

LADCP Utility

LADCP Description	LADCP-1
Invoking and Exiting the Utility	LADCP-2
LADCP Help Facility	LADCP-2
LADCP Commands	LADCP-3
BIND	LADCP-4
EXIT	LADCP-7
HELP	LADCP-8
SHOW SERVICES	LADCP-9
UNBIND	LADCP-11

Index

Tables

LASTCP-1 Summary of LASTCP Commands	LASTCP-4
LADCP-1 Summary of LADCP Commands	LADCP-3

Preface

Intended Audience

This manual is intended for OpenVMS system managers.

Document Structure

This document consists of two sections:

- A description of the LASTCP utility, which you use to start the LASTport transport and to monitor transport activity. This section explains how to start InfoServer Client for OpenVMS software automatically.
- A description of the LADCP utility, which you use to load the LASTport/Disk driver and to manage InfoServer device services.

Each section provides the following information:

- Invoking and exiting the utility
- Restrictions or privileges required
- Descriptions of commands, including format, parameters, and examples.

Related Documents

The following documents provide information about InfoServer systems:

- *InfoServer System Operations Guide*
- *InfoServer 100 Installation and Owner's Guide*
- *InfoServer 150 Installation and Owner's Guide*

Conventions

The following conventions are used in this manual:

Ctrl/x	A sequence such as Ctrl/x indicates that you must hold down the key labeled Ctrl while you press another key or a pointing device button.
Return	In examples, a key name is shown enclosed in a box to indicate that you press a key on the keyboard. (In text, a key name is not enclosed in a box.)
.	A vertical ellipsis indicates the omission of items from a code example or command format; the items are omitted because they are not important to the topic being discussed.
()	In format descriptions, parentheses indicate that, if you choose more than one option, you must enclose the choices in parentheses.
[]	In format descriptions, brackets indicate that whatever is enclosed within the brackets is optional; you can select none, one, or all of the choices. (Brackets are not, however, optional in the syntax of a directory name in a file specification or in the syntax of a substring specification in an assignment statement.)
red ink	Red ink indicates information that you must enter from the keyboard. For online versions of the book, user input is shown in bold .
boldface text	Boldface text represents the introduction of a new term or the name of an argument, an attribute, or a reason.
<i>italic text</i>	Italic text represents information that can vary in system messages (for example, Internal error <i>number</i>).
UPPERCASE TEXT	Uppercase letters indicate that you must enter a command (for example, enter OPEN/READ), or they indicate the name of a routine, the name of a file, the name of a file protection code, or the abbreviation for a system privilege.
numbers	Unless otherwise noted, all numbers in the text are assumed to be decimal. Nondecimal radices—binary, octal, or hexadecimal—are explicitly indicated.

LASTCP Utility

LASTCP Description

InfoServer Client for OpenVMS software uses the LASTport protocol to communicate with InfoServer systems on a local area network (LAN). The LASTport protocol is implemented in the OpenVMS device driver `ESS$LASTDRIVER`.

The LASTCP utility is the management interface that allows you to control and diagnose `ESS$LASTDRIVER`. You can use LASTCP to do the following:

- Start and stop `ESS$LASTDRIVER`
- Display counters for circuits, lines, nodes, and `ESS$LASTDRIVER`
- Display node characteristics
- Display known clients and servers
- Display LASTport status
- Reset counters

The description of the LASTCP utility covers the following topics:

- Invoking and exiting the utility
- LASTCP Help Facility
- Starting InfoServer Client for OpenVMS software automatically
- LASTCP commands

Invoking and Exiting the Utility

Use of LASTCP requires normal privileges, except where noted. To invoke LASTCP, enter the following command:

```
$ RUN SYS$SYSTEM:LASTCP
%LASTCP-I-VERSION, ESS$LASTDRIVER V1.5 is running
LASTCP>
```

At the LASTCP> prompt, you can enter LASTCP commands. To exit the utility, type EXIT or press Ctrl/z after the LASTCP> prompt.

You can also execute a single LASTCP command by using a DCL string assignment statement, as shown in the following example:

```
$ LASTCP == $LASTCP
$ LASTCP SHOW CLIENTS
```

LASTCP Description

LASTCP executes the SHOW CLIENTS command and returns control to DCL command level.

LASTCP Help Facility

LASTCP provides a Help Facility that contains information about each command and its parameters and qualifiers, as well as examples of its use. Refer to the HELP command description for more information about the LASTCP Help Facility.

Starting InfoServer Client for OpenVMS Software Automatically

You must edit the system startup files to provide for automatic startup and shutdown of InfoServer Client for OpenVMS software when your system is rebooted.

Add the command line that starts InfoServer Client for OpenVMS to the system startup file, SYS\$MANAGER:SYSTARTUP_V5.COM. You must position this new command line *after* the line that invokes the DECnet network startup command procedure. The following example shows the network startup command line followed by the InfoServer Client for OpenVMS startup command line. Note that if you omit the TAPE parameter, only the disk function is started.

```
$ @SYS$MANAGER:STARTNET
.
.
.
$ @SYS$STARTUP:ESS$STARTUP CLIENT TAPE
```

You can edit the file SYS\$STARTUP:ESS\$LAST_STARTUP.DAT to specify desired startup qualifiers.

Startup Restrictions: PATHWORKS and RSM

If PATHWORKS or RSM or both are installed, the InfoServer Client for OpenVMS startup must be run before the startup for PATHWORKS or RSM or both.

```
$ @SYS$MANAGER:STARTNET
.
.
.
$ @SYS$STARTUP:ESS$STARTUP CLIENT TAPE
$ @SYS$STARTUP:PCFS_STARTUP
$ @SYS$STARTUP:RSM$SERVER_STARTUP
```

InfoServer Client for OpenVMS software provides device drivers and control programs that are shared by both the PATHWORKS and RSM products. All InfoServer Client for OpenVMS components are prefixed with ESS\$. The drivers and control programs supplied with InfoServer Client for OpenVMS software provide all necessary support for both PATHWORKS and RSM in addition to InfoServer Client support. You must execute the InfoServer Client for OpenVMS startup in the site-specific startup before executing either the PATHWORKS or RSM startup procedures.

Startup Restrictions: SYSMAN

You cannot start InfoServer Client for OpenVMS from a subprocess. Because the OpenVMS System Management utility (SYSMAN) uses subprocesses to complete its tasks on remote nodes, SYSMAN cannot be used to execute the SYS\$STARTUP:ESS\$STARTUP procedure.

User Account Requirements

To work with InfoServer Client for OpenVMS software, user accounts on your system must have the following privileges and quotas:

- You need GRPNAM privilege if the /GROUP qualifier of the LADCP BIND command is used; SYSNAM privilege is required if the /SYSTEM qualifier of the LADCP BIND command is used.
- At a minimum, you need default UAF account quotas.

See the *VMS Authorize Utility Manual* for a description of how to verify and change account privileges and quotas.

SYSGEN Parameter MAXBUF Requirement

To use all the utility's SHOW functions, you must set the value of the SYSGEN parameter MAXBUF to 32000. This value is required to accommodate LASTDRIVER structures.

LASTCP Commands

Table LASTCP-1 summarizes LASTCP commands and their functions.

Table LASTCP-1 Summary of LASTCP Commands

Command	Function
EXIT	Returns the user to DCL command level
HELP	Displays HELP text for LASTCP commands
SHOW CLIENTS	Displays known clients
SHOW CIRCUIT COUNTERS	Displays circuit counters
SHOW LINE COUNTERS	Displays line counters
SHOW NODE CHARACTERISTICS	Displays node characteristics
SHOW NODE COUNTERS	Displays node counters
SHOW SERVERS	Displays known servers
SHOW STATUS	Displays local status
SHOW TRANSPORT COUNTERS	Displays transport counters
START TRANSPORT	Starts LASTDRIVER
STOP TRANSPORT	Stops LASTDRIVER
ZERO COUNTERS	Resets counters

You can abbreviate LASTCP commands to the first unique characters of the command verb. For example, you can abbreviate the command SHOW SERVERS to SH SE.

EXIT

Stops execution of LASTCP and returns control to DCL command level. You can also type Ctrl/z to exit at any time.

Format

EXIT

Parameters

None.

Example

```
LASTCP> EXIT
```

This command exits the LASTCP program and returns control to DCL command level.

LASTCP HELP

HELP

Provides online help information for using LASTCP commands.

Format

HELP [command-name]

Parameter

command-name

The name of a LASTCP command. If you enter the HELP command with a command name only, such as HELP SET, LASTCP displays a list of all of the command keywords used with the SET command.

Description

The HELP command is an online reference for LASTCP commands. After you view an initial help display, press RETURN. The help display stops and the LASTCP> prompt is displayed. If you do not specify a command name, the HELP command displays general information on the commands for which help is available. By supplying a command name, you can obtain syntax information for that command.

Example

```
LASTCP> HELP SHOW NODE
```

```
SHOW
```

```
  NODE
```

```
    SHOW    ACTIVE NODE    CHARACTERISTICS
           KNOWN NODE      COUNTERS
           NODE node-id
```

```
    Display counters or characteristics for the node(s) selected.
```

```
    Additional information available:
```

```
    examples
```

In this example, the HELP SHOW NODE command produces a description of the SHOW NODE command and shows the command format.

SHOW CIRCUIT COUNTERS

Displays the circuit counters maintained by the Ethernet data link driver. To use the **SHOW CIRCUIT COUNTERS** command, you must have **SYSPRV** and **SHARE** privileges.

Format

SHOW CIRCUIT COUNTERS

Parameters

None.

Qualifiers

/ALL_CONTROLLERS

Displays the circuit counters for all Ethernet controllers in use.

/CONTROLLERS=(letter)

Displays the circuit counters for the Ethernet controllers specified. To specify an Ethernet controller, determine the device's unit name in the form **ddcu**.

If you omit both the **/ALL_CONTROLLERS** and **/CONTROLLERS** qualifiers, LASTCP displays the counters for the first Ethernet controller.

Example

```
LASTCP> SHOW CIRCUIT COUNTERS /ALL_CONTROLLERS
```

```
Ethernet Circuit Counters on unit XQA3:
```

```
48938482  Bytes received
44263546  Bytes sent
 70647   Data blocks received
 66823   Data blocks sent
 0       Local buffer errors
 0       Multicast received but not enabled
```

```
Ethernet Circuit Counters on unit XQB3:
```

```
43241769  Bytes received
39768821  Bytes sent
 68976   Data blocks received
 60375   Data blocks sent
 0       Local buffer errors
 0       Multicast received but not enabled
```

This example shows the circuit counters for all Ethernet controllers in use.

LASTCP SHOW CLIENTS

SHOW CLIENTS

This command displays information for all known clients in the network.

Format

SHOW CLIENTS

Parameters

None.

Description

The information displayed includes the following:

- Node name, which is the client's DECnet node name.
- Node id, which is the client's hardware address and incarnation value. The incarnation value is an identifier assigned to each client each time the client is restarted.
- Physical address, which is the Ethernet address.
- Active links, which is the number of links the client has created.
- Start time, which is the time the client connected to the server. If the client is not connected, LASTCP displays a hyphen.

Example

```
LASTCP> SHOW CLIENTS
```

Node Name	Node Id	Physical Address	Active Links	Start Time
MAG357	08002B05B19B-2122	AA-00-04-00-59-25	1	-
THOLIN	08002B082600-3C2A	AA-00-04-00-40-26	0	-
XOCHTL	08002B080A5E-5D11	AA-00-04-00-05-25	0	-
BRONTE	08002B082415-101F	AA-00-04-00-1D-25	2	-
MILTON	08002B045CD1-050F	AA-00-04-00-2A-26	0	-
WOOLFE	08002B0308F5-4D19	AA-00-04-00-4D-25	0	-
WRONG	08002B045C6D-4711	AA-00-04-00-60-25	2	-
JIMF1	08002B045DDF-310F	AA-00-04-00-2A-27	1	-
SUMAC	08002B080645-0006	AA-00-04-00-42-25	0	-
BOOT	08002B040EEC-D723	08-00-2B-04-0E-EC	0	-

This command displays a list of all known clients.

SHOW LINE COUNTERS

Displays the line counters maintained by the Ethernet data link driver. To use this command, you must have SYSPRV and SHARE privileges.

Format

SHOW LINE COUNTERS

Parameters

None.

Qualifiers

/ALL_CONTROLLERS

Displays the line counters for all Ethernet controllers in use.

/CONTROLLERS=(letter)

Displays the line counters for the Ethernet controllers specified. To specify an Ethernet controller, determine the device's unit name in the form **ddcu**.

If you omit both the **/ALL_CONTROLLERS** and **/CONTROLLERS** qualifiers, LASTCP displays the counters for the first Ethernet controller.

Description

The line counters reflect all users of the data link for this controller. See the *VMS Network Control Program Manual* for a complete description of these counters.

LASTCP SHOW LINE COUNTERS

Example

```
LASTCP> SHOW LINE COUNTERS /ALL_CONTROLLERS
Ethernet Line Counters on unit XQA3:
  65535  Seconds since last zeroed
  521887 Receive frames
    12   Receive errors
  110796 Multicast frames received
 92535097 Receive bytes
 7018641 Multicast bytes received
 438736  Transmit frames
    0    Transmit errors
  32338  Multicast frames transmitted
 74717562 Transmit bytes
 2420463 Multicast bytes transmitted
   522   Frames sent, single collision
   606   Frames sent, multiple collisions
    0    Frames sent, initially deferred
    0    Transmit collision detect check failures
    0    Data overruns
    1    System buffer unavailable
    0    User buffers unavailable
    0    Unrecognized frame destination
```

This command displays the line counters for the first Ethernet controller.

SHOW NODE CHARACTERISTICS

Displays node characteristics for a specific node, all active nodes, or all known nodes.

Format

```
SHOW [NODE nodename][ACTIVE NODE][KNOWN NODE]  
CHARACTERISTICS
```

Parameters

NODE nodename

Specifies the DECnet node name of the client or server.

ACTIVE NODE

Specifies active nodes.

KNOWN NODE

Specifies known nodes.

Description

The node characteristics displayed are as follows:

- Node name, which is the client's or server's DECnet node name.
- Node id, which is the node's **hardware address** and **incarnation value**. The incarnation value is an identifier assigned to each node each time it is restarted.
- Physical address, which is the Ethernet address.
- Active links, which are the number of links the client has created.
- Start time, which is the time the client connected to the server. If the client is not connected or if the node is a server, LASTCP displays a hyphen.

LASTCP SHOW NODE CHARACTERISTICS

Example

```
LASTCP> SHOW NODE BRONTE CHARACTERISTICS
```

Node Name	Node Id	Physical Address	Active Links	Start Time
BRONTE	08002B082415-101F	AA-00-04-00-1D-25	0	-

This command displays node characteristic information for node BRONTE.

SHOW NODE COUNTERS

Displays the node counters that ESS\$LASTDRIVER maintains for a specific node, for all active nodes, or for all known nodes.

Format

```
SHOW [NODE nodename][ACTIVE NODE][KNOWN NODE] COUNTERS
```

Parameters

NODE nodename

Specifies the DECnet node name for the node whose counters you want to display.

ACTIVE NODE

Specifies that counters should be displayed for all active nodes.

KNOWN NODE

Specifies that counters should be displayed for all known nodes.

Description

The following counter information is displayed:

- The number of bytes received and sent
- The number of frames received and sent
- The number of commands received and sent

Example

```
LASTCP> SHOW NODE BRONTE COUNTERS
```

```
Node counters for node BRONTE
```

```
    2415 Bytes received  
   33144 Bytes sent  
     45 Frames received  
     57 Frames sent  
      0 Commands issued  
     17 Commands received
```

This command shows counters for node BRONTE.

LASTCP SHOW SERVERS

SHOW SERVERS

Displays information for all known servers in the network.

Format

SHOW SERVERS

Parameters

None.

Description

The information displayed includes the following:

- Node name, which is the server's DECnet node name.
- Node id, which is the server's hardware address and incarnation value. The incarnation value is an identifier assigned to each server each time ESS\$LASTDRIVER is started.
- Physical address, which is the Ethernet address. If a server has more than one Ethernet controller, all Ethernet addresses are displayed.
- Active links, which is the number of links the client has created. For the SHOW SERVERS command, active links are always 0.
- Start time, which is the time the client connected to the server. For the SHOW SERVERS command, start time is always a hyphen.

LASTCP SHOW SERVERS

Example

LASTCP> **SHOW SERVERS**

Node Name	Node Id	Physical Address	Active Links	Start Time
LETTER	08002B028F25-87C0	AA-00-04-00-12-26	0	-
AUTHOR	AA0003013C27-FA60	AA-00-04-00-83-27	0	-
WRITER	08002B035577-0BA0	AA-00-04-00-24-26	0	-
TYPIST	08002B02F0CC-6300	AA-00-04-00-5E-25	0	-
EDITOR	08002B039028-11A0	AA-00-04-00-42-26	0	-
PENCIL	AA00030108C1-3420	AA-00-04-00-08-24	0	-
CRAYON	08002B032BD0-8680	AA-00-04-00-5F-26	0	-
MARKER	08002B0210CC-87A0	AA-00-04-00-D7-25	0	-
PASTEL	08002B029814-44E0	AA-00-04-00-63-25	0	-
PAINTS	08002B06E9F1-E4E0	AA-00-04-00-9A-25	0	-
PINK	08002B02F51B-B9E0	AA-00-04-00-A1-27	0	-
BROWN	08002B0612B6-4980	AA-00-04-00-DA-25	0	-

This command shows all known servers.

LASTCP SHOW STATUS

SHOW STATUS

Displays the local status of ESS\$LASTDRIVER.

Format

SHOW STATUS

Parameters

None.

Example

```
$ RUN SYS$SYSTEM:LASTCP
%LASTCP-I-VERSION, ESS$LASTDRIVER V1.4 is running
LASTCP> SHOW STATUS

Status of ESS$LASTDRIVER V1.4 on node TDOG at 1-JAN-1990 15:56:55
Protocol version 3.0, Uptime: 15 06:35:43.14, Checksum Off,
Slow mode Off

66549 Bytes pool
  8 Ethernet buffers
 16 I/O request packets
  9 Association control blocks
  1 Local session control blocks
  0 LSC In-Use blocks
  2 Transaction control blocks
  9 Circuit status blocks
182 Node data blocks
  5 Transmit quota
 80 Maximum circuits
  0 LAN group code
  0 Server circuit timeout
```

This command displays the status of ESS\$LASTDRIVER. Note that the value of the Server circuit timeout is the value that was set with the START TRANSPORT/TIMEOUT command. If the /TIMEOUT qualifier is not used with the START TRANSPORT command, the Server circuit timeout value is zero, as in this example.

SHOW TRANSPORT COUNTERS

Displays the transport counters maintained by ESS\$LASTDRIVER.

Format

SHOW TRANSPORT COUNTERS

Parameters

None.

Qualifiers

/ALL_CONTROLLERS

Displays the circuit counters for all Ethernet controllers in use.

/CONTROLLERS=(letter)

Displays the transport counters for the Ethernet controllers specified. To specify an Ethernet controller, determine the device's unit name in the form **ddcu**.

If you omit both the **/ALL_CONTROLLERS** and **/CONTROLLERS** qualifiers, LASTCP displays the counters for the first Ethernet controller.

LASTCP SHOW TRANSPORT COUNTERS

Example

```
LASTCP> SHOW TRANSPORT COUNTERS /CONTROLLERS=(A)
```

```
ESS$LASTDRIVER Transport Counters for XQA3
```

```
    251608  Seconds since last zeroed
    5549774  Receive frames
           0  Receive multicasts
           0  Receive duplicates
           0  Receive errors
00000000  Last receive failure code
    6204594  Transmit frames
           0  Transmit errors
00000000  Last transmit failure code
           0  Retransmissions
           0  Datalink Restarts
           1  Protocol errors
00000001  Protocol error bit mask
           0  Checksum errors
           3  Client transaction aborts
           6  Server transaction aborts
           8  Missed segment request aborts
           0  No Transmit buffers
           0  Invalid transaction mode
           0  Illegal circuit ID
          211 Invalid multicast messages
           1  Congested circuit
Protocol errors include:
  Invalid run message
```

This command displays the transport counters for controller A.

START TRANSPORT

Initializes an Ethernet controller with the LAST protocol.

Format

SHOW SERVERS

Parameters

None.

Qualifiers

/ALL_CONTROLLERS

Initializes all present Ethernet controllers with the LASTport protocol. Do not use this qualifier with the /CONTROLLERS qualifier.

/CHECKSUM

Allows ESS\$LASTDRIVER to checksum all messages sent and received. By default, /CHECKSUM is not enabled.

/CIRCUIT_MAXIMUM=n

Specifies the maximum number of clients that can connect to the disk server. The number of clients can be in the range of 1 to 65535. By default, 80 clients can connect to the disk server.

/CONTROLLERS=(letter[,...])

Initializes the specified Ethernet controllers with the LASTport protocol. Do not use this qualifier with the /ALL_CONTROLLERS qualifier. By default, LASTCP initializes the first Ethernet controller. To specify an Ethernet controller, determine the device's unit name in the form **ddcu**.

/GROUP=n

Is the group code to associate with the disk server. By default, the group code is 0. If you assign a group code to a disk server, only workstations with the same group code can connect to services offered by the server.

/NODENAME=name

Initializes ESS\$LASTDRIVER with the specified node name. By default, LASTCP uses the DECnet node name.

LASTCP START TRANSPORT

/SLOW_MODE

Forces remote transports to transmit only one segment at a time. Use this qualifier *only* when a transmitter can transmit at a faster rate than the local node can receive. By default, /SLOW_MODE is not enabled.

/TIMEOUT=n

Specifies the minimum interval in seconds to be used by the server transport to determine when inactive clients should be disconnected. An inactive client is one that has been turned off or otherwise isolated from the server.

By default, the server's timer is specified by the client transport. This qualifier allows a minimum value to be enforced on all connections.

The letter n represents an integer value in the range of 60 to 65535 seconds.

/TRANSMIT_QUOTA=n

Limits the number of concurrent message buffers that ESS\$LASTDRIVER can transmit for each transaction. The default transmit quota is five message buffers.

Description

By default, ESS\$LASTDRIVER is started on all Ethernet controllers on the system.

The START TRANSPORT command is also included in the LAD_STARTUP.COM file, so the transport is started automatically.

To use the START TRANSPORT command, you must have CMKRNL and SYSPRV privileges. Start the transport *after* you start DECnet. DECnet does not start properly if you start the transport first.

Examples

1. LASTCP> **START TRANSPORT /CONTROLLERS=(A)**
%LASTCP-I-STARTED, ESS\$LASTDRIVER V1.4 started on node NODE2
%LASTCP-I-ADAPINIT, Initializing adapter XQA6: for ESS\$LASTDRIVER
LASTCP>

The command in this example starts ESS\$LASTDRIVER and initializes controller A.

LASTCP START TRANSPORT

2. LASTCP> **START TRANSPORT /ALL_CONTROLLERS /CIRCUIT_MAXIMUM=50**
%LASTCP-I-STARTED, ESS\$LASTDRIVER V1.4 started on node NODE2
%LASTCP-I-ADAPINIT, Initializing adapter XQA6: for ESS\$LASTDRIVER
%LASTCP-I-ADAPINIT, Initializing adapter XQB6: for ESS\$LASTDRIVER
LASTCP>

The command in this example starts starts ESS\$LASTDRIVER, initializes all controllers, and limits the number of client connections to 50.

LASTCP STOP TRANSPORT

STOP TRANSPORT

Stops ESS\$LASTDRIVER. To use the STOP TRANSPORT command, you must have CMKRNL and SYSPRV privileges.

Format

STOP TRANSPORT

Parameters

None.

Description

Any active sessions are aborted and all system dynamic memory is returned.

If you are using PATHWORKS, you must shut down PATHWORKS using normal PATHWORKS procedures before stopping the LASTport transport.

Example

```
LASTCP> STOP TRANSPORT  
%LASTCP-I-STOPPED, ESS$LASTDRIVER stopped  
LASTCP>
```

This command example stops ESS\$LASTDRIVER.

ZERO COUNTERS

Resets circuit, transport or node-specific counters maintained by the Ethernet datalink or LASTport drivers.

Format

ZERO [NODE nodename][CIRCUIT][TRANSPORT] COUNTERS

Parameters

NODE nodename

Specifies the DECnet node name of the client whose counters you want to reset.

CIRCUIT

Specifies the circuit whose counters you want to reset.

TRANSPORT

Specifies the transport whose counters you want to reset.

Examples

1. LASTCP> **ZERO CIRCUIT COUNTERS**
%LASTCP-I-ZEROCIRC, Circuit counters zeroed
LASTCP>

This command resets the circuit counters on all Ethernet controllers initialized with the LASTport protocol.

2. LASTCP> **ZERO TRANSPORT COUNTERS**
%LASTCP-I-ZEROTRAN, Transport counters zeroed
LASTCP>

This command resets the transport counters on all Ethernet controllers initialized with the LASTport protocol.

3. LASTCP> **ZERO NODE FLUX COUNTERS**
%LASTCP-I-ZERONODE, Node counters for FLUX zeroed
LASTCP>

This command resets the counters for node FLUX.

LADCP Utility

LADCP Description

You use the LADCP utility to configure and control the LASTport/Disk and LASTport/Tape protocols on OpenVMS host systems. OpenVMS systems that use LASTport/Disk and LASTport/Tape services are called client nodes. You can use LADCP to do the following:

- Establish **bindings** to services. A binding creates a new DAD*n*: virtual disk unit or a new MAD*n*: virtual tape unit on the local OpenVMS system.
- Remove bindings to services.

You can control service access by using a service access password. You can also write-protect services. In this case, local OpenVMS users of a DAD*n*: or MAD*n*: device unit receive an error if they attempt a write operation to the unit.

The protocols allow you to access media that reside on an InfoServer system as though they were locally connected to your OpenVMS system. Thus, several OpenVMS client nodes can share the same media, eliminating the need for duplicate drives and media.

DAD*n*: and MAD*n*: device units are also referred to as **virtual device units**. They represent the local OpenVMS context for a volume that resides on a remote server. The OpenVMS driver that controls the DAD*n*: units is called ESS\$DADDRIVER. The OpenVMS driver that controls the MAD*n*: units is called ESS\$MADDRIVER.

The LASTport/Disk and LASTport/Tape protocols depend on the LASTport transport. The ESS\$STARTUP.COM command procedure in SYS\$MANAGER automatically loads ESS\$DADDRIVER and ESS\$MADDRIVER as well as ESS\$LASTDRIVER, the local area system transport driver.

Note

Your site-specific startup command procedure must include a call to ESS\$STARTUP.COM. If you are using DECnet software, you must place the call *after* the SYS\$MANAGER:STARTNET.COM command that starts DECnet software.

LADCP Description

Invoking and Exiting the Utility

To invoke LADCP, enter the following command:

```
$ RUN SYS$SYSTEM:ESS$LADCP
LADCP>
```

You can enter LADCP commands at the LADCP> prompt.

You can also execute a single LADCP command by using a DCL string assignment statement, as shown in the following example:

```
$ LADCP ::= $ESS$LADCP
$ LADCP BIND CD_DOC_00661 /NOWRITE
```

LADCP executes the BIND command and returns control to DCL command level.

To exit LADCP, type EXIT or press Ctrl/z after the LADCP> prompt.

LADCP Help Facility

LADCP provides a Help facility that contains information about each LADCP command, including parameters, qualifiers, and examples of its use. See the HELP command description for more information about the LADCP Help facility.

LADCP Commands

Table LADCP-1 summarizes LADCP commands and their functions.

Table LADCP-1 Summary of LADCP Commands

Command	Function
BIND	Establishes a LAD service binding and creates a device unit.
EXIT	Returns the user to DCL command level.
HELP	Displays help text for LADCP commands.
SHOW SERVICES	Displays services offered by all available InfoServer systems on the network.
UNBIND	Eliminates an established LAD service binding.

BIND

Establishes a binding to a LASTport/Disk or LASTport/Tape service and creates a DAD*n*: virtual disk unit or a MAD*n*: virtual tape unit.

Format

BIND service-name

Parameter

service-name

Specifies the name of the service to bind to. This name can be up to 255 ASCII characters long. You can use any of the valid characters in the following list. Services are offered to the OpenVMS client node by InfoServer systems. Usually, a service name is the same as the volume label of the disk or tape volume to which the InfoServer system is providing access.

If you assign an InfoServer name, you can use only the following set of characters:

- A–Z
- a–z
- 0–9
- \$ (dollar sign)
- . (period)
- _ (underscore)
- - (hyphen)
- Multinational characters in the ASCII range 192–255

All InfoServer names are case insensitive. For example, InfoServer software treats an uppercase A and a lowercase a as the same character.

Qualifiers

/[NO]ASYNCHRONOUS

Specifies whether all write requests should complete immediately. The default is /NOASYNCHRONOUS. /NOASYNCHRONOUS prevents the write request from completing until the data has been written to the remote physical disk volume. /ASYNCHRONOUS results in faster response times.

/CONNECT

Valid only with the **/TAPE** qualifier. If **/CONNECT** is specified, LADCP immediately attempts a network connection to the service and returns the status of the attempt.

/DISK

Indicates that the service to bind to is a virtual disk. This is the default qualifier.

/GROUP

Specifies whether a logical name of the form **DAD\$service-name** or **MAD\$service-name** is placed in the group logical name table. The variable *service-name* is the name of the service for which a binding is being established. This logical name points to the **DADn:** or **MADn:** virtual device unit that the **BIND** command creates. **GRPNAM** privilege is required to use this qualifier.

/PASSWORD=password-string

Specifies an optional service access control password. The password is required if the InfoServer system requires password protection for the specified service name. The password string can be up to 39 ASCII characters long.

/SYSTEM

Specifies whether a logical name of the form **DAD\$service-name** or **MAD\$service-name** is placed in the system logical name table. The value *service-name* is the name of the service for which a binding is being established. This logical name points to the **DADn:** or **MADn:** virtual device unit that the **BIND** command creates. **SYSNAM** privilege is required to use this qualifier.

/TAPE

Indicates that the service to bind to is a virtual tape service.

/[NO]WRITE_ENABLE

Tells the **ESS\$DADDRIVER** to allow the OpenVMS user write access to the service. The default is **/NOWRITE_ENABLE**.

Description

The **BIND** command creates a local **DADn:** or **MADn:** device unit on the OpenVMS system, representing a service binding between the local node and the remote volume. This **DADn:** or **MADn:** virtual device unit provides the local context for the remote volume and is the target of user I/O operations. A logical name in the form **DAD\$service-name** (or **MAD\$service-name**) is placed in the process logical name table and points to the virtual device unit.

Use the **UNBIND** command to eliminate an existing binding.

LADCP BIND

Examples

1. LADCP> **BIND CD_DOC_00661/SYSTEM**
%LADCP-I-BIND, service bound to logical unit DAD\$CD_DOC_00661 (_DAD10:)
\$ **MOUNT/SYSTEM DAD\$CD_DOC_00661 CD_DOC_00661**

In this example, the BIND command creates a DAD n : unit named DAD10: that is the target of user I/O requests to access a remote disk volume named CD_DOC_00661. The logical name DAD\$CD_DOC_00661 is placed in the process logical name table as well as in the system logical name table, providing a more convenient name for the virtual disk unit. The user would then enter the DCL command MOUNT/SYSTEM to make the remote disk volume available for file operations to all users on the local OpenVMS system.

2. LADCP> **BIND VIRTUAL_DISK/WRITE/NOASYNC**
%LADCP-I-BIND, service bound to logical unit DAD\$VIRTUAL_DISK (_DAD12:)

In this example, the BIND command creates a device for the VIRTUAL_DISK service name and creates the logical name DAD\$VIRTUAL_DISK to point to this device. It also specifies that any write request performed is written before the write request completes.

3. LADCP> **BIND/TAPE/CONNECT TAPE_DRIVE**
%LADCP-I-CONNAvail, successful connection to service TAPE_DRIVE
%LADCP-I-BIND, service bound to logical unit MAD\$TAPE_DRIVE (_MAD2:)

In this example, the BIND command creates a device for the TAPE_DRIVE read/write logical tape service and creates the logical name MAD\$TAPE_DRIVE to point to the device. LADCP immediately attempts to form a connection to the service.

EXIT

Stops execution of LADCP and returns control to DCL command level. You can also press Ctrl/z to exit at any time.

Format

EXIT

Parameters

None.

Example

```
LADCP> EXIT
```

In this example, the **EXIT** command exits the LADCP program and returns control to DCL command level.

LADCP HELP

HELP

Provides online help information for using LADCP commands.

Format

HELP [command-name]

Parameter

command-name

Specifies the name of a LADCP command. If you enter the HELP command with a command name only, such as HELP BIND, LADCP displays a list of all of the command keywords used with the BIND command.

Description

The HELP command is an online reference for LADCP commands. After you view an initial help display, press Return. The help display stops, and the system displays the LADCP> prompt. If you do not specify a command name, the HELP command displays general information on the commands for which help is available. Specifying a command name displays syntax information on that command.

Example

```
LADCP> HELP BIND
```

In this example, the HELP BIND command displays a description of the BIND command and the command format.

SHOW SERVICES

Displays services offered by all available InfoServer systems on the network.

Format

SHOW SERVICES

Parameters

None.

Qualifiers

/All

Displays all available services.

/Disk

Displays disk services. This is the default display.

/Tape

Displays tape services.

Description

The SHOW SERVICES command provides the following information:

- Service name of the service offered, such as ONLINE_DOC.
- Type of device containing the service, such as RRD42.
- Service rating—higher ratings indicate better service.
- Current connects.
- Whether writes are allowed to the device.

LADCP SHOW SERVICES

Example

LADCP> **SHOW SERVICES**

Interrogating network, please wait...

Services offered by node LIBRARY_ESS (LAD V3.1, Address: 08-00-2B-XX-XX-XX)

Service:	Device:	Rating:	Current Connects:	Writes Allowed?:
ONLINE_DOC	RRD42	64751	1	No
CONDIST3	RRD42	64760	3	No
CONDIST2	RRD42	64751	4	No
CONDIST1	RRD42	64751	4	No
VXT_FONT_SET_BL4X	RZ23L	65016	0	Yes
.				
.				
.				

In this example, the **SHOW SERVICES** command displays information about available disk services.

UNBIND

Ends an existing binding between the local OpenVMS system and a remote disk or tape volume.

Format

UNBIND client-device

Parameter

client-device

Specifies the name of the virtual device unit that represents the service binding. This name is either the name of the *DADn:* or *MADn:* unit returned in the BIND command or the logical name (*DAD\$service-name* or *MAD\$service-name*) created by the BIND command to point to the *DADn:* or *MADn:* unit.

Description

The UNBIND command unbinds a client device from a service name and deletes the device. This command breaks any existing connections for the client device and deletes it when all channels to the device have been deassigned.

You cannot UNBIND a device that has been mounted. Once a client device has been mounted, you must use the DCL command DISMOUNT/UNLOAD to delete the client device. For tape clients, this is the only way to break the network connection to the service and delete the unit.

You use the LADCP UNBIND command only when a service binding is created that cannot be mounted (for example, a service name is entered incorrectly) or when a service must be deleted for any other reason.

To end a service binding, follow these steps:

1 If the *DADn:* or *MADn:* unit is mounted

- Notify all users of the service to stop performing I/O requests to the corresponding unit.
- Dismount the unit using the DCL command DISMOUNT/UNLOAD. This command ends the binding and automatically deletes the unit.

LADCP UNBIND

2 If the DADn: or MADn: unit is not mounted

- Enter the LADCP UNBIND command to end the binding and delete the DADn: or MADn: unit.

Nonprivileged users can use the UNBIND command only for a virtual device unit that they created with a BIND command. BYPASS privilege is required to unbind a virtual disk unit not owned by the user.

Example

```
LADCP> UNBIND DAD$CD_DOC_00661
%LADCP-E-MOUNTED, cannot UNBIND a mounted device
%LADCP-I-DISMOUNT, please use OpenVMS command DISMOUNT/UNLOAD to delete unit
```

In this example, the UNBIND command returns an error because the DADn: unit is mounted. The user must enter the DCL command DISMOUNT /UNLOAD to end the binding and delete the DADn: unit. Note that the LADCP command UNBIND is not needed after a DCL command DISMOUNT /NOUNLOAD.

Index

D

DAD virtual disk unit, LADCP-1

E

ESS\$LASTDRIVER, LASTCP-1, LADCP-1
controlling and diagnosing, LASTCP-1
ESS\$STARTUP.COM, LADCP-1

I

InfoServer Client for OpenVMS software,
LASTCP-1
starting automatically, LASTCP-2
startup restrictions, LASTCP-2
InfoServer system, LADCP-1, LADCP-4

L

LADCP commands

BIND, LADCP-4
EXIT, LADCP-7
HELP, LADCP-8
SHOW SERVICES, LADCP-9
UNBIND, LADCP-11

LADCP utility

command summary, LADCP-3
exiting, LADCP-2, LADCP-7
Help Facility, LADCP-2
invoking, LADCP-2

LASTCP commands

EXIT, LASTCP-5
HELP, LASTCP-6

LASTCP commands (cont'd)

SHOW CIRCUIT COUNTERS,
LASTCP-7

SHOW CLIENTS, LASTCP-8

SHOW LINE COUNTERS, LASTCP-9

SHOW NODE CHARACTERISTICS,
LASTCP-11

SHOW NODE COUNTERS, LASTCP-13

SHOW SERVERS, LASTCP-14

SHOW STATUS, LASTCP-16

SHOW TRANSPORT COUNTERS,
LASTCP-17

START TRANSPORT, LASTCP-19

STOP TRANSPORT, LASTCP-22

ZERO COUNTERS, LASTCP-23

LASTCP utility, LASTCP-1

account requirements, LASTCP-3

command summary, LASTCP-4

exiting, LASTCP-1

Help Facility, LASTCP-2

invoking, LASTCP-1

privileges required, LASTCP-1

LASTport transport, LASTCP-1, LADCP-1

starting, LASTCP-19

stopping, LASTCP-22

LASTport/Disk service, LADCP-1

binding, LADCP-4, LADCP-5

ending a service binding, LADCP-11

ESS\$DADDRIVER, LADCP-1

LASTport/Tape service, LADCP-1

binding, LADCP-4, LADCP-5

ending a service binding, LADCP-11

ESS\$MADDRIVER, LADCP-1

M

MAD virtual tape unit, LADCP-1

P

PATHWORKS

startup restrictions, LASTCP-2

R

RSM

startup restrictions, LASTCP-2

S

Service

bindings, LADCP-1

password protection, LADCP-1

write protection, LADCP-1

Startup restrictions

InfoServer Client for OpenVMS software,
LASTCP-2

PATHWORKS, LASTCP-2

RSM, LASTCP-2

SYSMAN, LASTCP-3

SYSMAN

startup restrictions, LASTCP-3

U

UNBIND command, LADCP-11

How to Order Additional Documentation

Technical Support

If you need help deciding which documentation best meets your needs, call 800-343-4040 before placing your electronic, telephone, or direct mail order.

Electronic Orders

To place an order at the Electronic Store, dial 800-DEC-DEMO (800-332-3366) using a 1200- or 2400-baud modem. If you need assistance using the Electronic Store, call 800-DIGITAL (800-344-4825).

Telephone and Direct Mail Orders

Your Location	Call	Contact
Continental USA, Alaska, or Hawaii	800-DIGITAL	Digital Equipment Corporation P.O. Box CS2008 Nashua, New Hampshire 03061
Puerto Rico	809-754-7575	Local Digital subsidiary
Canada	800-267-6215	Digital Equipment of Canada Attn: DECdirect Operations KAO2/2 P.O. Box 13000 100 Herzberg Road Kanata, Ontario, Canada K2K 2A6
International	_____	Local Digital subsidiary or approved distributor
Internal ¹	_____	USASSB Order Processing - WMO/E15 <i>or</i> U.S. Area Software Supply Business Digital Equipment Corporation Westminster, Massachusetts 01473

¹For internal orders, you must submit an Internal Software Order Form (EN-01740-07).

Reader's Comments

InfoServer Client for OpenVMS
LASTCP and LADCP Utilities

AA-PT4DA-TE

Please use this postage-paid form to comment on this manual. If you require a written reply to a software problem and are eligible to receive one under Software Performance Report (SPR) service, submit your comments on an SPR form.

Thank you for your assistance.

I rate this manual's:	Excellent	Good	Fair	Poor
Accuracy (software works as manual says)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (enough information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clarity (easy to understand)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (structure of subject matter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Figures (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Examples (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Index (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Page layout (easy to find information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

I would like to see more/less _____

What I like best about this manual is _____

What I like least about this manual is _____

I found the following errors in this manual:

Page	Description
_____	_____
_____	_____
_____	_____

Additional comments or suggestions to improve this manual:

I am using **Version** _____ of the software this manual describes.

Name/Title _____ Dept. _____

Company _____ Date _____

Mailing Address _____

Phone _____

Do Not Tear - Fold Here and Tape

digital™



AFFIX
STAMP
HERE

DIGITAL EQUIPMENT CORPORATION
Corporate User Information Products
ZKO1-3/J35
110 SPIT BROOK RD
NASHUA, NH 03062-9987



Do Not Tear - Fold Here

digital